



Epson Stylus NX230 Ink Cartridge Replacement

This guide is meant to show how to replace ink cartridges within the printer.

Written By: Danielle Purdy



INTRODUCTION

The ink cartridges allow you to print in a variety of colors, or simply in black and white. If one of the ink cartridges is empty, then you will need to replace it.

Step 1 — Ink Cartridge



- Open the top of the printer so that the inside of the printer is visible.
- ⓘ The ink cartridges should be visible.

Step 2



- Grab the top of the cartridge that you need to replace and press in on the tab at the top of the cartridge.
- Pull the cartridge up and out of the ink tray

To reassemble your device, follow these instructions in reverse order.